






**Amigo (Pre 96)**  
**HARDTOP INSTALLATION INSTRUCTION SHEET**

**PARTS LIST**

	Mount Hooks (MHK) X 6		Screw (SCR) X 6
	Joint Bracket (BRK5) X 3		Speed Knob (SKB-1) X 3
	Gasket (GSK3) X 45"		

**Installation Instructions:**

1. Remove the soft-top and bow assembly used to anchor the soft top. Three screws must be removed from each side located at base assembly.
2. Remove the screw snaps (25) along the factory rubber. **Do not remove the screw snaps on the tailgate!** Do not remove the factory rubber! Do not remove the two screws located at the back end of the rubber, one of each side of tailgate must remain.
3. Place the provided 45" Gasket (GSK3) along the top edge of the vehicle from side to side over the factory rubber.
4. Place your new Hardtop over the area of the vehicle. Start by placing the front of the top over the 45" gasket. Continue until entire top is in place. Push down on top to make sure it is in place.
5. Place the provided Mount Hooks (MHK), over the designated holes and secure with screws (SCR) provided.
6. Repeat item #5 on the other side of the vehicle.
7. Close the cam locks (n\mounted on inside of top) over the Mount Hooks.
8. At rear of Amigo Hardtop, on inside, is another set of cam locks already mounted. Extend each cam lock to its longest position. Align the Mount Hook to the cam lock, and mark inside the hole on the side panel. At this point, drill one 1/8" hole or use self-tapping screw (SCR), provided.
9. Place the cam lock clip over the newly drilled/tapped hole and screw on with the self-tapping screw provided to the rear side quarter panel.
10. Repeat steps 8 and 9 for attaching the cam lock and Mount Hooks to the other rear side quarter panel.
11. Close the cam locks over the cam lock clips. Make sure to check all cam locks for securing the Hardtop!

**YOUR NEW AMIGO HARDTOP IS NOW IN PLACE!**